

## MOSFETS Selector Guide

TYPE	DESCRIPTION	CHANNEL	GATE(S)	SUPPLY VOLTAGE (V <sub>DS</sub> )	PACKAGE
PHN205	Low ohmic battery switch	N&N	Dual	25	S08 (SOT96)
PHP212	Low ohmic battery switch	P&P	Dual	25	S08 (SOT96)
PHC20512	Low ohmic battery switch	N&P	Dual	25	S08 (SOT96)
PHN103	Low ohmic battery switch	N	Single	30	S08 (SOT96)
PHP109	Low ohmic battery switch	P	Single	30	S08 (SOT96)
BSP030	Low ohmic battery switch	N	Single	30	S08 (SOT96)
BSP090	Low ohmic battery switch	P	Single	30	S08 (SOT96)

TYPE	DESCRIPTION	CHANNEL	GATE(S)	SUPPLY VOLTAGE (V <sub>DS</sub> )	PACKAGE
BF904	Mixer/oscillator	N&P	Dual	3 to 7	SOT143
BF904WR	Mixer/oscillator	N&P	Dual	3 to 7	SOT343
BF909	Mixer/oscillator	N&P	Dual	3 to 7	SOT143
BF909WR	Mixer/oscillator	N&P	Dual	3 to 7	SOT343

TYPE	DESCRIPTION	CHANNEL	GATE(S)	SUPPLY VOLTAGE (V <sub>DS</sub> )	PACKAGE
BSN254	Line interrupter/ground switch	N	Single	250	SOT54
BSN304	Line interrupter/ground switch	N	Single	300	SOT54
BSP126	Line interrupter/ground switch	N	Single	250	SOT223
BSP130	Line interrupter/ground switch	N	Single	300	SOT223
VN2406L	Line interrupter/ground switch	N	Single	240	SOT54
BSP92	Line interrupter/ground switch	P	Single	240	SOT54
BSP225	Line interrupter/ground switch	P	Single	250	SOT223
BSP224	Line interrupter/ground switch	P	Single	250	SOT54
BSP304	Line interrupter/ground switch	P	Single	250	SOT223